

Regulators

Pin-indexing safety system

May be built in



Supplemental Oxygen

All patients in cardiac arrest should get oxygen.

Any patient with a respiratory or cardiac emergency needs oxygen.

Never withhold oxygen from anybody that may benefit from it.

Why do I care! I hate math!

Patient is placed on a nonrebreather at 15 LPM. Transport time is 15 minutes. D-Cylinder Tank pressure reads 800 psi.

Chart shows CF=0.16

$$\frac{(800 - 200) \times 0.16}{15} = 6.4 \text{ minutes}$$